

Peugeot Boxer_560291_116044e.pdf - Foxit Phantom - [Peugeot Boxer_560291_116044e.pdf]

Файл(F) Правка(E) Организация(O) Вид(V) Комментарии(C) Формы(F) Защита(S) Инструменты(T) Помощь(H)

Find

Peugeot Boxer_560291_116044e

Required Components	Part Number
DTCO	1381-0081000005 illumination orange, dimming A 2, w/o CAN
DTCO	1381-0061200001 illumination green, dimming A 2, w/o CAN D1+D2
KITAS	2171-01000000
KITAS cable	2170-80220280
Connecting cable connector A	1318-90100000
Mounting frame	1324-90010500

The following Peugeot parts are required for KITAS installation:

	Position	Peugeot Part Number	Description
	1	2649 53	Gear wheel
	2	2641 52	Bearing
	4	2645 12	Gasket
	5	2651 04	Gasket
	6	2641 53	Shaft
	70	2644 06	Washer
	72	6928 01	Screw
	3	is not required	

1 / 2 152.21% Размер: [8.26 * 11.69 B]

пущ 1С:Предприятие ... Skype™ - a.turov... http://www.roadr... IMG_20131219_1... Автомобили Peugeot Boxer_56... RU 15:26